



GENERAL DESCRIPTION

Junckers StrongPlus is a 1-component water-based low odour hard-wearing lacquer for wooden floors in high traffic commercial and residential areas.

The product is suitable for previously sealed as well as on new or sanded older floors.

When lacquering an untreated floor or floor sanded to bare wood, use one of Junckers primers prior to the finishing top seal. This to prevent any gluing effect between the floor boards.

PRODUCT DESCRIPTION

Product: 1-component water-based polyurethane lacquer.

Package sizes: 5 litre.

Appearance: Creamy/milky in the container. Colourless film when dry.

Gloss: Ultra matt, Matt, Silk Matt.

TECHNICAL DATA

Coverage: 10-12 m² per litre.

Before application: Stir or shake the lacquer well before use.

Application tools: Brush, roller, air/airless spray.
Don't apply by pouring out the lacquer directly on the floor.

Substrate temperature: Minimum 15° C.

Dilution: Delivered ready for use. Dilution is not recommended.

Drying time:
Approx. 3 hours at 20° C and 50 % RH.
Fully cured after 72 hours.
Apply only 2 coats of lacquer per day.

RH:
Water-based products have a certain gluing effect and are therefore recommended only to be used in rooms with a stable humidity. This means that the difference between the highest and lowest relative humidity should not fluctuate more than 30 % over the year.

Cleaning of tools: Soap and water before drying of the lacquer.

Storage: Lasts for 1 year if unopened and stored at 20° C. Not to be exposed to temperatures below 0° C.

SYSTEM RECOMMENDATIONS

High traffic commercial and residential areas:

1 coat Junckers PreLak 8 m²/litre + 2 coats Junckers StrongPlus 10 m²/litre
or

1 coat Junckers ProSeal 10 m²/litre + 2 coats Junckers StrongPlus 10 m²/litre
or

1 coat Junckers BasePrime 10 m²/litre + 2 coats Junckers StrongPlus 10 m²/litre.

DIRECTION FOR USE

Untreated/Sanded Floors:

Ensure that the surface is absolutely clean, dry and free from dust, wax, grease, polish, soap residues etc. Sand the surface to remove dirt and irregularities. Vacuum thoroughly and wipe off with a cloth well wrung in clean water.

Prime with one coat of Junckers PreLak, Junckers ProSeal or BasePrime. Leave to dry. Sand with 150-180 grit sandpaper along the fibres of the wood. Vacuum sanding dust and wipe off with a cloth well wrung in clean water.

Apply one coat of Junckers StrongPlus. Leave to dry overnight and then apply the finishing coat.

Previously sealed floors:

Clean with Junckers SylvaNeutralizer. Sand thoroughly using grit 150-180. Vacuum sanding dust and wipe off with a well wrung cloth and clean water.

Trial applications should be conducted on a couple of spots, 2 coats at 4 hours interval. After drying for 24 hours check the spots for adhesion by scraping with the edge of a coin. If the adhesion is functioning and the appearance of the surface is acceptable, the floor can be sealed with one coat of Junckers StrongPlus.

If the trial application is not satisfactory, proceed as described under "Wax/Polish Treated floors".

Wax/Polish treated Floors:

Machine sand by first using grit 24-36 to strip old coats. Then remove abrasion marks using grit 60-80. Finally, use grit 120-150 to obtain a completely smooth surface. Vacuum thoroughly. Treat the floor as described under "Untreated/ Sanded floors".

IMPORTANT

Before using the product, read the label on the container carefully and observe the recommended precautionary measures. See Material Safety Data Sheet for detailed information about precautionary measures.

FURTHER INFORMATION

Products:

F 5.3 - Junckers PreLak
F 6.4 - Junckers BasePrime
F 8.6 - Junckers ProSeal
F 10.3 - Junckers SylvaNeutralizer